

TRANSPORTMASTER MODELS

Type	Make	Model Name	Model Number	Model Years	4x2, 4x4	DRW/SRW	Fuel	GAWR Rear Max (lbs)	RG RD Model #	Notes	
CHASSIS CAB (truck chassis) (not pickup truck)	GM	Chevrolet Silverado HD Chassis Cab	C3500	2011-2019	4x2	DRW	Gas/Diesel	9750	RD975C-AM	For use with varying load (like box truck)	
		GMC Sierra HD Chassis Cab							RD975CLP-AM	For use with constant load on rear axle (like ambulance)	
	Ford	Super Duty Chassis Cab	F350	2011-2016	4x2, 4x4*	DRW	Gas/Diesel	9750	RD975F8-AM		
				2017-2020	4x2, 4x4*	DRW	Gas/Diesel	10040	RD1004F-AM		
			F450	2011-2016	4x2, 4x4*	DRW	Gas/Diesel	12000	RD11KDF8-AM		
				2017-2020	4x2, 4x4*	DRW	Gas/Diesel	12880	RD1288F-AM		
			F550	2011-2016	4x2, 4x4*	DRW	Gas/Diesel	14706	RD1370F8-AM		
				2017-2020	4x2, 4x4*	DRW	Gas/Diesel	14706	RD1470F-AM RD1470FLC-AM	Low Crossmember - 1 inch higher than the OEM frame rail	
	Ram	Heavy Duty Chassis Cab	3500	2013-2020	4x2, 4x4	DRW	Gas/Diesel	9850	RD975D13-AM		
			4500	2013-2020	4x2, 4x4	DRW	Gas/Diesel	12000	RD1200DA13-AM	SALES/CS - RIDE HEIGHT NEEDS TO BE CONFIRMED AT TIME OF INSTALLATION AUDIT - PLEASE CONTACT ENGINEERING	
			5500	2011-2012	4x2, 4x4	DRW	Gas/Diesel	13500	RD1350D-AM		
	CUTAWAY / E-SERIES STRIPPED CHASSIS (van chassis)	GM	Chevrolet Express Cutaway Van	G3500	2011-2020		DRW	Gas/Diesel	8660	RD866C-AM	
			GMC Savana Cutaway Van	G4500	2011-2020		DRW	Gas/Diesel	9600	RD960C-AM	
Ford		E-Series Cutaway Van E-Series Stripped Chassis	E350	2011-2021		DRW	Gas/Diesel	8500	RD800F-AM	SALES/CS - FIRST UNIT INSTALL AUDIT NEEDED FOR E-SERIES STRIPPED CHASSIS	
			E450	2011-2021		DRW	Gas/Diesel	9600	RD950F-AM	SALES/CS - FIRST UNIT INSTALL AUDIT NEEDED FOR E-SERIES STRIPPED CHASSIS	

*Fords - 4x4 - Do NOT use axle spacer, if one exists, Remove it.